

# **2-Serial/1-Parallel Port PCI Adapter**

## **User Manual**

**Ver. 3.00**

**All brand names and trademarks are properties of their  
respective owners.**

## ***Features and Benefits***

Features	<ul style="list-style-type: none"><li>● Compliant with PCI Local Bus Specification, Revision 2.3</li><li>● Supports 2 x UART serial ports</li><li>● Add one IEEE 1284 Parallel Port on system</li><li>● Easy Plug and Play</li><li>● Automatically selects IRQ &amp; I/O address</li><li>● Built-in 16C450/550 compatible UART</li><li>● On chip 256 byte FIFOs in transmit and receive path of each serial port</li><li>● Serial data transfer rate up to 115200bps</li><li>● Supports Standard Parallel Port (SPP), Enhanced Parallel (EPP) &amp; Enhanced Capability Port (ECP)</li><li>● Parallel data transfer rate up to 1.5Mbytes/sec</li></ul>
Bus	<ul style="list-style-type: none"><li>● PCI 32-bit</li></ul>
Connectors	<ul style="list-style-type: none"><li>● 2 x DB9 male serial connectors</li><li>● 1 x DB25 female parallel connector</li></ul>

## ***System Requirements***

- Windows® XP/Vista/7 (32/64 bit)
- Available PCI slot

## ***Package Contents***

- 1 x 2-Serial/1-Parallel Port PCI Adapter
- 1 x Bracket with two DB9 male serial ports
- 1 x Driver CD
- 1 x User Manual

## ***Hardware Installation***

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCI slot.
4. To install the card, carefully align the card's bus connector with the selected PCI slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Replace the computer cover and reconnect the power cord.

## ***Driver Installation***

Put the driver CD in your CD-ROM drive. The CD-ROM will start automatically. Click “Install Driver” to start the installation. Follow the instructions on screen to install the driver. After driver installation is complete, you must restart your computer.

## ***To Verify Driver Installation***

Click on the **Device Manager** tab in System Properties, which you access from the Windows Control Panel. You should see two **High-Speed PCI Serial Port ...** and one **PCI ECP Parallel Port ...** installed under **Ports (COM & LPT)** item.