

2-Port Parallel PCI Adapter

User Manual

Ver. 3.00

**All brand names and trademarks are properties of their
respective owners.**

Features and Benefits

- Features
- Compliant with PCI Local Bus Specification, Revision 2.3
 - Add two IEEE 1284 Parallel Ports on system
 - Easy Plug and Play
 - Automatically selects IRQ & I/O address
 - Supports Standard Parallel Port (SPP), Enhanced Parallel (EPP) & Enhanced Capability Port (ECP)
 - Faster data rates up to 1.5Mbytes/sec
- Bus
- PCI 32-bit
- Connectors
- 2 x DB25 female parallel connectors

System Requirements

- Windows® XP/Vista/7 (32/64 bit)
- Available PCI slot

Package Contents

- 1 x 2-Port Parallel PCI Adapter

- 1 x Bracket with one DB25 female parallel port
- 1 x Driver CD
- 1 x User Manual

Hardware Installation

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCI slot.
4. To install the card, carefully align the card's bus connector with the selected PCI slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Replace the computer cover and reconnect the power cord.

Driver Installation

Put the driver CD in your CD-ROM drive. The CD-ROM will start automatically. Click "Install Driver" to start the installation. Follow the instructions on screen to install the driver. After driver installation is complete, you must restart your computer.

To Verify Driver Installation

Click on the **Device Manager** tab in System Properties, which you access from the Windows Control Panel. You should see two **PCI ECP Parallel Port ...** installed under **Ports (COM & LPT)** item.