

# **2-Port Serial PCIe Adapter**

## **User Manual**

**Ver. 1.00**

**All brand names and trademarks are properties of their  
respective owners.**

## ***Features and Benefits***

- Features
- Compliant with PCI Express Base Specification 1.1
  - Supports 2 x UART serial port
  - Built-in 16C450/550 compatible UART
  - On chip 256 byte FIFOs in transmit and receive path of each serial port
  - Data transfer rate up to 230400bps
- Bus
- PCI-Express x1
- Connectors
- 2 x DB9 male serial connectors

## ***System Requirements***

- Windows® XP/Vista/7 (32/64 bit)
- PCI Express-enabled system with an available PCI Express slot

## ***Package Contents***

- 1 x 2-Port Serial PCIe Adapter
- 1 x Driver CD

- 1 x User Manual

## ***Hardware Installation***

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCIe slot.
4. To install the card, carefully align the card's bus connector with the selected PCIe slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Replace the computer cover and reconnect the power cord.

## ***Driver Installation***

Put the driver CD in your CD-ROM drive. The CD-ROM will start automatically. Click "Install Driver" to start the installation. Follow the instructions on screen to install the driver. After driver installation is complete, you must restart your computer.